



RHINO

CAR AUDIO

Installation Guide

1 Surface Preparation

Clean the surface thoroughly with isopropyl alcohol or a degreaser. Remove any rust, loose paint, or debris. The surface must be completely clean and dry. For optimal adhesion, apply when ambient temperature is between 41°F-113°F (5°C-45°C).

2 Measure and Plan

Measure the area to be covered and create a layout plan. Due to the 7mm thickness, RhinoLuxe 3.0 is best suited for large, flat areas like floors, trunks, and door panels. Plan for 60-80% coverage for maximum performance.

3 Cut to Size

Use sharp scissors or a utility knife to cut the material. Cut pieces slightly larger than needed for precision trimming. For curved surfaces, make relief cuts to help the material conform without bunching.

4 Apply Material

Peel back the release liner gradually and position the material. Start from the center and work outward to prevent air bubbles. The pressure-sensitive adhesive provides strong initial tack.

5 Roll for Maximum Adhesion

Use a roller tool to firmly press the material into place, ensuring complete surface contact. Pay special attention to edges. The adhesive will reach full bond strength within 24-48 hours.